




FUSELAGE




WING BOX




VER. STB.



HOR. STB.








NOSE GEAR



BL

Use this area for ballast (see Instruction Manual for more guidance)





BL

Use this area for ballast (see Instruction Manual for more guidance)

